

Injectronics

Remanufactured Automotive Electronics Components

TECHNICAL BULLETIN

Document number: T0065

For further technical information regarding testing, repairs or to search for New or Remanufactured Automotive electronic products, please visit www.injectronics.com.au, call our office on (+613) 8792 6999, or email sales@injectronics.com.au

Make: Volkswagen

Model: Transporter

Subject: Installation of ECM, basic settings

From the early / mid 1990's many VW / Audi ECM's had the ability of adaptive learning from inputs such as RPM, O2 sensor value, engine load signal (AFM, MAF or MAP), Throttle position etc.

These inputs and learnt values are used to determine the initial start point (base setting) of outputs such as idle speed, fuel mixture etc.

When installing one of these ECM's it is desirable to connect a V.A.G. (Volkswagen) scan tool (or equivalent) and go through the procedure of 'Basic Settings', which then programs the ECM to learn the vehicles engine characteristics. The engine will usually idle and accelerate smoother after doing this. The only other way is to drive the vehicle for some time so that the ECM learns the appropriate values. How long this time is, at this stage Injelectronics have not been able to determine and the manufacturers do not specify.

When remanufacturing VW Transporters 4 and 5 Cylinder ECM's with an internal map sensor, Injelectronics sets the base setting so that the ECM will see a throttle position voltage of .9 volts as a closed throttle. The fuel mixture will also be set slightly on the rich side of normal. This will usually enable the engine to run reasonably on first start up.

However, if your vehicle's TPS voltage is different or your fuel requirements of your engine are different (eg blocked injectors) you may experience poor idle or even poor initial acceleration. If you experience this and you do not have a tool to do basic settings, you may wish to set your TPS voltage to .90 volts, but only do this if your vehicle is a manual. The automatic transmission ECM also uses the TPS voltage and if this value is changed then the transmission ECM will also need 'Basic Setting' performed on it. You will also need time for the vehicle to respond and learn from the O2 sensor, so it is imperative that this sensor is operating correctly. The best method of 'Teaching' the ECM to learn values is to drive the vehicle once the operating temperature is reached and the O2 sensor is cycling. For more information on performing basic setting, please don't hesitate to call Injelectronics.

T0065.doc

This publication is distributed with the understanding that the authors, editors and publishers are not responsible for the results of any actions or works of whatsoever kind undertaken on the basis of information contained in this publication, nor for any errors or omissions contained herein. The publishers, authors and editors expressly disclaim all and any liability to any person whomsoever whether a purchaser of this publication or not in respect of anything and of the consequences of anything done or omitted to be done by any such persons in reliance, whether whole or partial upon the whole or any part of the contents of this publication. Injelectronics Australia Pty Ltd. © Copyright 2001.