

Injectronics

Remanufactured Automotive Electronics Components

TECHNICAL BULLETIN

Document number: T0107

For further technical information regarding testing, repairs or to search for New or Remanufactured Automotive electronic products, please visit www.injectronics.com.au, call our office on (+613) 8792 6999, or email sales@injectronics.com.au

Make: Toyota

Model: Rav 4 2001

Subject: Engine wont start or vehicle runs erratically

TEST: Check ground wiring 1-8 volts at the ECM.

Disconnect the ignition coil/igniter connector terminal one at a time and check the engine operation.

Does the engine start easy yes /no, engine will run on 3 cylinders.

CAUSE: Ignition coil/igniter assembly creates a high ground voltage.

Replace the ignition coil.

T0107.doc

This publication is distributed with the understanding that the authors, editors and publishers are not responsible for the results of any actions or works of whatsoever kind undertaken on the basis of information contained in this publication, nor for any errors or omissions contained herein. The publishers, authors and editors expressly disclaim all and any liability to any person whomsoever whether a purchaser of this publication or not in respect of anything and of the consequences of anything done or omitted to be done by any such persons in reliance, whether whole or partial upon the whole or any part of the contents of this publication. Injectronics Australia Pty Ltd. © Copyright 2001.