

Injectronics

Remanufactured Automotive Electronics Components

TECHNICAL BULLETIN

Document number: T0103

For further technical information regarding testing, repairs or to search for New or Remanufactured Automotive electronic products, please visit www.injectronics.com.au, call our office on (+613) 8792 6999, or email sales@injectronics.com.au

Make: Jeep

Model: Cherokee 4.0L

Subject: Engine will not start

TEST: Check for ignition & injection pulses while cranking the engine. Check for 5 volt supply voltage to the various sensors e.g. CRANK, CAM, MAP & TPS. If no 5 volt supply voltage is evident, disconnect the crankshaft position sensor located on the bell housing & check if the 5 volt supply is evident at the various sensors.

CAUSE: The crankshaft position sensor pulls the 5 volt supply voltage low.

Replace the crankshaft position sensor.

T0103.doc

This publication is distributed with the understanding that the authors, editors and publishers are not responsible for the results of any actions or works of whatsoever kind undertaken on the basis of information contained in this publication, nor for any errors or omissions contained herein. The publishers, authors and editors expressly disclaim all and any liability to any person whomsoever whether a purchaser of this publication or not in respect of anything and of the consequences of anything done or omitted to be done by any such persons in reliance, whether whole or partial upon the whole or any part of the contents of this publication. Injectronics Australia Pty Ltd. © Copyright 2001.